



FIGURE - 9A

DYNAPACK INSTALLATION
TYPICAL THROUGH A WALL

SEE INSTALLATION MANUAL
FOR ADDITIONAL DETAILS